

MULTIZONE CLOCKS

LEDI® **WORLD**



Tri-colors



*Display several time-zones
on the same clock*



GORGY  TIMING

L A M A R Q U E D U T E M P S

www.gorgy-timing.com/en

New-generation LEDI®WORLD

A range of truly professional clocks.

- **Matt-finish anodised aluminium case:**

for wall-mounting or flush-fitting. Its Reverso case is IP30 rated for standard single and double face version and IP54 for the waterproof version. IK9 shock-resistant.

- **Anti-glare front face:**

specifically treated against scratches, eliminates 80% of reflections due to outdoor light.

LEDI®WORLD 5.60



- **Multilingual:**

Names of cities in the language of your choice.

- **Optimum legibility:**

White marking against a black background. Names of towns on request.

- **Tri-colour LEDs:**

To change or mix the colour of the time display to red, green or amber yellow by the user at any time. Blue or white on option. Also on option: tri-colours display with very high luminescence.

- **Specific light guides:**

For better viewing angle up to 160°.

- **Power supply:**

230V.
Low voltage.
POE (Power Over Ethernet).
Multi POE.

A WIDE RANGE OF OPTIONS

- **Single and double sided display.**
- **From 2 to 7 time-zones on the same clock (more on request).**
- **Display: hour, minute - hour, minute, second - hour, minute, circle line for seconds.**
- **Height of numbers: 50mm and 70mm.**
- **Possibility of colour settings of your display simply and easily.**

- **Temperature-compensated TCXO quartz timebase:**

the integrated electronics constantly adjust the frequency of the quartz according to temperature variations for accuracy worthy of a professional clock...
Operating range: between -20°C and 70°C.

- **Operation of the timebase:**

Standalone or radio-synchronised to France Inter, DCF, GPS. Synchronised by an external source :
- Minute or ½ minute impulse.
- ASCII, IRIGB, AFNOR NFS 87500, SMPTE EBU time codes.
- NTP protocol.
- Wireless radio 869Mhz.
- Wi-Fi 802.11b and 802.11g.



LEDI®WORLD 7 double-face



Your customised LEDI®WORLD clock

Development on request.



LEDI®WORLD 7 - 8 time zones



Especially designed for situation rooms

Environmentally-friendly clock

Recyclable aluminium, low electricity consumption, ROHS compliant, recyclable packaging, PEFC compliant documentation, estimated lifetime of over 20 years, etc...



New Generation LEDI® Definitely professional



Choose a GORGYTIMING Ledi®World clock to...

- Equip a trading room
- Crisis room
- Reception hall (hotel, company, shop, etc.)
- Airport
- School, university.
- Etc.



OPTIONAL SERVICES*

- Presales support.
- Training and Commissioning Assistance.
- Technical support.
- Pre-configuration and complete configuration of the product in the factory, on-site or remotely.
- Maintenance contract.
- Installation.

* Information available from the GORGYTIMING sales department.

CERTIFICATIONS



All GORGYTIMING product ranges comply with the following standards:

- **CE, EN 60950** (safety), **EN 55022** (EMC emission), **EN 55024** (EMC immunity), **ROHS**.
- **ISO 9001** and **ISO 14001** certified company.



MADE IN FRANCE



L A M A R Q U E D U T E M P S

Quartier Beauregard - 38350 La Mure d'Isère (Grenoble France).
Tel : +33 476 30 48 20 Fax : +33 476 30 85 33
e.mail : gorgy@gorgy-timing.fr - www.gorgy-timing.com